




# POWER UNIT QUICK START GUIDE

## IMPORTANT

Before operating this equipment, read the full operator's manual by visiting [osoelectric.com/support](http://osoelectric.com/support)



## MAIN COMPONENTS



## SPEED CONTROL

\*MAX   
SPEED 4   
SPEED 3   
SPEED 2   
SPEED 1



*\*When in MAX all 5 GREEN lights will blink*

## STATUS LIGHTS

TOP DOWN FROM OSO LOGO

**GREEN**  
POWERED ON  
 **BLUE**  
(GPS SIGNAL IF CONTRACTED)  
 **ORANGE**  
LOW BATTERY INDICATOR

**ALL ORANGE**  
 **OVERHEAT INDICATOR**  
(Wait until unit cools down)

**ALL RED**  
 **FAULT / CALL SERVICE**

## BASIC OPERATION

READ AND UNDERSTAND THE OPERATOR'S MANUAL BEFORE USING THIS PRODUCT.

1) Ensure the BATTERY is properly connected. 2) Turn the MAIN SWITCH to the ON position. 3) Choose a SPEED setting (if needed).

**IF OVERHEATED, DO NOT DISCONNECT THE BATTERY. KEEPING THE BATTERY CONNECTED WILL ENSURE THE INTERNAL FAN KEEPS RUNNING AND COOLS OFF THE UNIT FASTER.**